

plumbing retrofits!

CITY OF POMPANO BEACH WATER CUSTOMERS



low-flow showerhead

SAVE 7,300 GALLONS OF
WATER/YEAR



bathroom faucet aerator

SAVE 7,665 GALLONS OF
WATER/YEAR



kitchen faucet aerator

SAVE 1,916 GALLONS OF
WATER/YEAR



Florida's Warmest Welcome

enjoy your
water savings!

Questions? Call (954) 545-7015

installing your retrofits:

low-flow showerhead



1. Remove the old showerhead. A wrench may be required, so use a cloth to protect the finish.
 2. Turn on the water to wash out the pipe.
 3. Turn off the water, and screw on the new showerhead.
 4. Test your showerhead! If it leaks, you may need to tighten or add plumber's tape.
-

bathroom and kitchen faucet aerators



1. Remove the old aerator. A wrench may be required, so use a cloth to protect the finish.
2. Turn on the water to wash out the pipe.
3. Turn off the water, and screw on the new aerator. Hand tighten!
4. Turn on the water. If the aerator leaks, tighten with a wrench. Don't over-tighten!

Note: Use 1 rubber washer for faucets with external threads.
Use 2 rubber washers for faucets with internal threads.